

# EZ-WRAP - ALL TYPES

## INSTALLATION INSTRUCTIONS



**USE PRIMER BASED ON APPLICATION**

### PRIMER INSTRUCTIONS

1. Stir primer thoroughly before application to ensure rubber solids are equally dispensed throughout the solution. Using a paint brush or roller apply a thin even coat of EZ-STIK #4 PRIMER all the way around the joint. Prime the area at least 2" wider than the width of the EZ-WRAP used.
2. Allow the solvents dispense from the primed surface (10-30 minutes depending on temperature), so that a clean, smooth surface is ready for installation of the EZ-WRAP.

### SPRAY ADHESIVE INSTRUCTIONS

1. Shake well prior to use.
2. Surfaces should be clean, dry and free of debris.
3. Spray adhesive using a web pattern to ensure coverage.
4. Allow solvent to flash for 1 to 3 minutes, until tacky, and then press rubber to adhesive.

1. Clean the exterior surfaces of the joint area. Make sure that the cleaned area is at least 2" wider than the width of the EZ-WRAP used and that the cleaned area is centered on the joint. The concrete must be dry before applying wrap, adhesive or primer. Primer is most important when installing in cold temperatures.
  - **Using primer or spray adhesive are recommended options for best installation results. SEE INSTRUCTIONS TO LEFT.**
2. Cut the EZ-Wrap to the correct length prior to applying it to the joint. The below table will give you an idea of the most common lengths
3. The butyl sealant side of EZ-WRAP is protected by release paper. Apply the EZ-WRAP to the structure, taking care to centering it so both sides of the joint are equally covered; remove the release paper as you apply the EZ-WRAP. Press the EZ-WRAP down firmly and evenly as you cover the joint area. A rubber roller may be used to assist in applying even pressure.
4. Complete the seal by overlapping the EZ-WRAP 6 to 9 inches. Apply #4 EZ STIK Primer to the section of EZ-Wrap attached to the manhole that will be covered by the overlap; let the solvents dispense from the #4 EZ STIK Primer; press the overlapped end firmly against the installed EZ-WRAP.

48" ID X 5" wall	16 feet
60" ID X 6" wall	20 feet
72" ID X 7" wall	24 feet

**CAUTION:** Never apply EZ-WRAP to wet #4 EZ STIK Primer.



Press-Seal believes all information is accurate as of its publication date. Information, specifications, and prices are all subject to change without notice. Press-Seal is not responsible for any inadvertent errors. Copyright 2024.

Phone: 800-348-7325  
Fax: (260) 436-1908

**PRESS-SEAL CORPORATION**  
Protecting Our Planet's Clean Water Supply  
ISO 9001: Registered • Version 09.10.24.10.14

Email: sales@press-seal.com  
Web: www.press-seal.com